Subject: Re: Question About Sony PS-LX220
Posted by Grayson Lassor on Thu, 03 Jun 2004 00:05:57 GMT
View Forum Message <> Reply to Message

If you get no answer using Wayne's idea try this; Swap turntable's phono leads at amp, if problem switches channels, turntables connections at cartridge or elsewhere are bad or phono cable connection is bad or "loose'(solder). Phono cable may be bad (open)If problem does't change channels amp is probably at fault. Of course cartridge may be bad. Hope you solve problem. glassor Grayson Lassor