Subject: as the record plays my strobe doesnt show a steady mark
Posted by sanspolanco on Sat, 02 Jul 2005 10:39:41 GMT
View Forum Message <> Reply to Message

does this always happen with belt drive turntables or is my turntable just crap? let me try to better describe my problem. whenever i play a record, the steady, non-moving marker flashed by my strobe starks to move as if i have slightly increased the speed. any suggestions?