Subject: Turntable Trouble
Posted by lauren on Thu, 27 Dec 2007 23:22:27 GMT
View Forum Message <> Reply to Message

I just got a new turntable, a Crosley and it wont start turning, when I turn the tone arm to the right, nothing happens, and it does so far, we are afraid to break it. Customer support has been no help, and I was wandering if ayone had some ideas?