Subject: CROSLEY KEEPSAKE TURNTABLE STOPPED SPINNING
Posted by BETTY on Tue, 03 Jun 2008 11:38:03 GMT
View Forum Message <> Reply to Message

I'VE HAD MY RECORD PLAYER FOR 5 MONTHS NOW, I USE IT DAILY, WHEN I WENT TO LISTEN TO A RECORD EARLIER IT WOULD NOT WORK. THE MOTOR IS NOT MOVING, THERE IS NO SOUND WHEN I RUB THE NEEDLE, THE BELT IS NOT LOOSE OR BROKEN, WHAT COULD BE THE PROBLEM? IT WAS WORKING FINE YESTERDAY..