Subject: Lenco 35
Posted by James@sideways-on.freeser on Mon, 20 Dec 2004 10:44:10 GMT
View Forum Message <> Reply to Message

Excuse my total ignorance! I've just bought a Lenco 35, and the turntable will only turn when the volume knob is switched to zero (rather than -/+). Any ideas what the problem could be?