Subject: MP3 Player Hates Weezer
Posted by Nymeria on Mon, 23 Jul 2012 20:00:40 GMT
View Forum Message <> Reply to Message

For some reason, my mp3 player always freezes up when playing a Weezer mp3. It'll play part of the song, then stop. I can't get it to restart or move to another track, so I turn the player off and back on and then it works again. It's so strange; it'll happen with any one of the 5 Weezer songs I have, but no other artist's songs.

Subject: Re: MP3 Player Hates Weezer
Posted by audioaudio90 on Wed, 25 Jul 2012 14:44:27 GMT
View Forum Message <> Reply to Message

That is really odd. Did you download all of the mp3s from the same place? It's got to be some sort of data issue within all of them if it doesn't happen with any other song. Do you notice the same issue when playing the mp3s on your computer?