Subject: Sony PS-LX250H Turntable, Auto mechanism problem
Posted by bpage on Mon, 28 Mar 2005 10:41:40 GMT
View Forum Message <> Reply to Message

Hello , i've recently bought a the PS-LX250H turntable from Sony, and the playing of records is just fine except for one problem... When pressing the "start" button to auto-play a record, the arm lifts, slides to the record, puts the stylus down normally, but 2 secs later, it picks up the stylus, and gets back into the off position and the turntalbe stops. What could be wrong? Thanks B. Page

Subject: Re: Sony PS-LX250H Turntable, Auto mechanism problem
Posted by Manualblock on Mon, 28 Mar 2005 12:07:29 GMT
View Forum Message <> Reply to Message

You need to open the table and look underneath. There are two arms and a pair of gears that move the arm. When the arm stops too soon it is most liklely that one of the gears is either mis-aligned or the rubber band that puts tension on the rotating gear arm is worn out.You can play with it but it probably needs someone who does this.

Subject: Re: Sony PS-LX250H Turntable, Auto mechanism problem
Posted by bpage on Tue, 29 Mar 2005 12:34:04 GMT
View Forum Message <> Reply to Message

thanks manualblock, ill try tonight