Subject: why won't my turntable play clear vinyl?
Posted by scottyrobotty on Sun, 09 Oct 2005 05:15:54 GMT
View Forum Message <> Reply to Message

clear of even semi-transparent vinyl of any color. when i start it the arm will go over near the edge of the record and then it will stop and go back to it's rest. it's a sony ps-636.any clues on how i can override this safeguard? i can't find a sensor anywhere.

Subject: Re: why won't my turntable play clear vinyl?
Posted by Wayne Parham on Sun, 09 Oct 2005 07:06:22 GMT
View Forum Message <> Reply to Message

That's an interesting symptom.  You might get the service manual and see if there is any info there.  If nothing else, at least you'll have the manual.

Subject: Re: why won't my turntable play clear vinyl?
Posted by Manualblock on Sun, 09 Oct 2005 12:20:55 GMT
View Forum Message <> Reply to Message

The manual might be hard to find since it doesn't exist.

Subject: Re: why won't my turntable play clear vinyl?
Posted by Dominic on Tue, 11 Oct 2005 20:36:31 GMT
View Forum Message <> Reply to Message

try putting some black paper underneath it.

Subject: Re: why won't my turntable play clear vinyl?
Posted by Paul C. on Tue, 07 Mar 2006 04:51:13 GMT
View Forum Message <> Reply to Message

I think you need to color the edge of the clear LP with a green magic marker...(No, don't do this, it is a joke meant to offend gullible people)