Subject: Sony PS-LX250H Stop Button
Posted by Scott on Wed, 29 Mar 2006 20:54:04 GMT
View Forum Message <> Reply to Message

I recently purchased a Sony PS-LX250H turntable as is, so there is no warranty.The Stop button isn't working. I've taken it apart and cannot figure out what the spring for this button is suppose to trigger to stop the turntable. Any help would be appreciated!