Subject: Sony LX250H turntable
Posted by marie riley on Sun, 04 Feb 2007 22:55:03 GMT
View Forum Message <> Reply to Message

The turntable suddenly will not turn. It is a year old and infrequently used. We took off the actual turntable and replaced the rubber band as instructed, but it still won't turn. What troubleshooting should we try?

Subject: Re: Sony LX250H turntable
Posted by Wayne Parham on Mon, 05 Feb 2007 18:21:00 GMT
View Forum Message <> Reply to Message

Is the motor turning?