Subject: belt for Sony PS-LX250H
Posted by ssmriga on Mon, 09 Jul 2007 00:06:45 GMT
View Forum Message <> Reply to Message

I own a Sony PS-LX250H which is a belt-drive turntable. The belt has come undone and I would like to rethread it. I have downloaded the users manual but there is no map available. Also, no luck searching the internet. Can anyone help? The best would be for someone that owns the same model to take a picture of the belt setup and email it to me so that I can use it as a guide.Thanks for the help!

Subject: Re: belt for Sony PS-LX250H
Posted by Wayne Parham on Tue, 10 Jul 2007 15:55:16 GMT
View Forum Message <> Reply to Message

Doesn't the platter have holes to access the belt? Look under the pad and see if there are holes in the platter.