Subject: Sony TC-650 reel deck brakes
Posted by Larry Sturtz on Wed, 21 Feb 2007 00:19:03 GMT
View Forum Message <> Reply to Message

Subject deck works well except when stopping in mid-rewind.Left hand takeup reel stops smoothly but right hand reel continues in motion unspooling 12+ inches of tape before stopping. When the tensioner resets it usually, but not always, breaks the tape.Have cleaned reel hub and inspected brake and cleaned brake pads. Any direction on how to fix?