Subject: Ward Airline
Posted by Tricia on Thu, 23 Oct 2008 20:51:58 GMT
View Forum Message <> Reply to Message

I think mine is a 50s version. The turntable turns, but no sound comes out. I'd like to get rid of it but have no idea how. Any ideas?