Subject: Bypassing Caps Posted by Manualblock on Wed, 19 Jan 2005 00:09:16 GMT View Forum Message <> Reply to Message

Would anyone be so kind as to try and explain why and how bypassing electrolytic caps in a PS with small polyprops can restore the lost high frequencies due to the electrolytics, to the signal? I have a hard time with understanding that. Thanks; J.R.

Page 1 of 1 ---- Generated from AudioRoundTable.com