Subject: What about volume pot impedance? Posted by Bill Epstein on Fri, 25 Jul 2008 12:50:39 GMT View Forum Message <> Reply to Message

Both my sources have output impedii (?) of less than 1000 ohms. I just received a 10k PEC pot to try in place of the 100k in my passive. Seems like 100k is a de facto standard for pre-amps pots and attenuators. If most of these have output impedances below 1000 ohms and the favorable ratio is 1:10, why is this?