

---

Subject: Re: Forgot link

Posted by [cfranz](#) on Fri, 27 Mar 2009 22:38:06 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You got to be more careful with placement and shielding because they throw a lot of RF noise. Other than that, why not if it's inexpensive enough. I've got a preamp that I run from a 12v wall wart which is a switching supply. Every now and again I have some issues with it and grunge. For what it's worth. Nowhere near the expert some of the other guys are.

---