
Subject: Re: Time frame?

Posted by [BillEpstein](#) on Wed, 22 Dec 2004 08:44:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

Not sure what you mean. Drying time? Kick plate is indeed the chassis plate. I just priced copper and brass 20 ga. 6x10 plates at [onlinemetals.com](#), they were \$16 and \$12 respectively with \$10 freight charge. 2 things to watch with the mitre and tape: 1) No matter how I have cut the mitres, there are always some gaps; easy to fix by saving some sawdust and mixing it with a little white glue to make a paste and filling. 2) I have switched from white or yellow carpenter's glue to the dreaded polyurethane because butt mitres with the former just aren't strong enough to hold up when you plane and sand or, worse, try to chop or rout holes for plugs and such. Definitely chop all mortises before glue up. Highly recommend cutting dados for splines to strengthen the joint
