
Subject: Re: Need 15 watt plus SET design for DIY?
Posted by [akhilesh](#) on Thu, 13 Oct 2005 20:23:45 GMT
[View Forum Message](#) <> [Reply to Message](#)

Try a parallel 300b: 18 watts. OR any parallel Pentode design, wired in triode mode: like an e134...should give you plenty of power!-akhilesh
