

---

Subject: Re: PS Regulation

Posted by [SteveBrown](#) on Tue, 12 Sep 2006 13:47:40 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

My favorite scheme is to use shunt regulation with a CCS on top of gas regulators. This is simple and extremely effective. I try to pass 2 -3 time the circuit current through the shunt. I've had this make a remarkable difference in the bass quality in particular. A shunt would be harder to do in an output stage, but easy in driver and preamp stages. I do bypass the gas tubes with a teflon cap, something around 0.1uf or so seems to do fine.

---