
Subject: Re: Actual bias vs set bias/antiskate
Posted by [Russellc](#) on Mon, 06 Dec 2004 16:39:54 GMT
[View Forum Message](#) <> [Reply to Message](#)

The "perifery" (or however its spelled) isn't all that heavy, and what ever you would have to do to make it move would probably be disasterous with or without the clamp! I never used any dampening on the platter out of balance concerns, that will damage the bearing. what exactly do you mean by "filling the suspension with hot glue"? russellc
