Subject: High frequency dispersion and driver size
Posted by DanTheMan on Fri, 09 Mar 2007 21:48:57 GMT
View Forum Message <> Reply to Message

Does anyone nkow how to calculate when a driver of any particular size will start beamimg? I know I've read the formula somewhere before, but I can't find it. Also, does anyone know how to use this information to find how high a given driver will go before its high frequency response reaches 90degree or 80degree.....dispersion?Thanks!Dan