Subject: A heretical tip from a heretic. Posted by Bill Fitzmaurice on Fri, 09 Apr 2004 11:02:26 GMT View Forum Message <> Reply to Message

Leave the angled reflectors out. With a low pass at 150 Hz or lower thay aren't necessary. Makes construction a lot easier, lightens the box, lessens materials cost. The purists will wail but trust me, they aren't necessary.

Page 1 of 1 ---- Generated from AudioRoundTable.com