Subject: Re: Padding questions
Posted by Bill Fitzmaurice on Tue, 10 Aug 2004 11:12:10 GMT
View Forum Message <> Reply to Message

The best way to go about it is to use temporary wire-wound 25ohm potentiometers to determine the required values in circuit and then put in the appropriate sized high power(12 watt) Mills non-inductive resisitors, available at Parts Express.