

---

Subject: Re: Padding questions

Posted by [Bill Fitzmaurice](#) on Tue, 10 Aug 2004 11:12:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The best way to go about it is to use temporary wire-wound 25ohm potentiometers to determine the required values in circuit and then put in the appropriate sized high power(12 watt) Mills non-inductive resisitors, available at Parts Express.

---