

---

Subject: Re: Padding questions

Posted by [Wayne Parham](#) on Fri, 13 Aug 2004 02:44:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Small wire won't allow much power, acting like a fuse instead. I'd suggest a good quality non-inductive resistor is probably your best bet. Both tubes and solid state alike use carbon resistors within the amp.

---