Subject: Re: Padding questions
Posted by Wayne Parham on Fri, 13 Aug 2004 02:44:43 GMT
View Forum Message <> Reply to Message

Small wire won't allow much power, acting like a fuse instead. I'd suggest a good quality non-inductive resistor is probably your best bet. Both tubes and solid state alike use carbon resistors within the amp.