

---

Subject: Re: horn surfaces

Posted by [Wayne Parham](#) on Fri, 31 Dec 2004 18:30:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

It depends on the frequency, and surface irregularities are a matter of scale. At low bass frequencies, even a very rough stair-step curve for a flare wall surface is fine. Bass wavelengths are measured in dozens of feet, so deviations on the surface can be several inches and not matter. But at 20kHz, the wavelength is about an inch and a half, so I would rather have a pretty smooth tweeter flare.

---