Subject: Re: System impedence Posted by Wayne Parham on Mon, 24 Jan 2005 00:03:39 GMT View Forum Message <> Reply to Message

If you don't have 16 ohm taps, then you might want to use 8 ohm speakers. It isn't a real bad mismatch, but it probably will rob some of your power transfer and might hurt bass response too.