

---

Subject: Re: Reference distance

Posted by [Bill Fitzmaurice](#) on Tue, 08 Mar 2005 19:12:23 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Pink noise measuring 6 to 9dB lower than sine is about right, as your source has its power spread across the spectrum. I usually measure at 2 meters to minimize multipathing and then add 6dB to get the 1 meter result.

---