Subject: Re: Reference distance
Posted by Bill Fitzmaurice on Tue, 08 Mar 2005 19:12:23 GMT
View Forum Message <> Reply to Message

Pink noise measuring 6 to 9dB lower than sine is about right, as your source has its power spread across the spectrum. I usually measure at 2 meters to minimize multipathing and then add 6dB to get the 1 meter rsult.