
Subject: Filling behind the horn of the A7/828 cabinet
Posted by [wunhuanglo](#) on Sat, 06 Aug 2005 18:27:45 GMT
[View Forum Message](#) <> [Reply to Message](#)

Seems that a lot of people advocate filling behind the horn with concrete, but does that ever add some weight. If you want to take the curse off, try 8 parts vermiculite to 1 part portland - ends up about 20 pounds per cubic foot, vs about 150 pounds per cubic foot for conventional mix. I've been thinking that I might try casting some large horns with it this fall (emphasis on "thinking")
Vermiculite is good for you!
