

---

Subject: Re: Sub placement

Posted by [akhilesh](#) on Wed, 22 Feb 2006 21:56:22 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I keep mine asymmetrical, and close to mains. This eliminates accentuation of nulls on any one frequency. -akhilesh

---