

---

Subject: Corner loading

Posted by [Wayne Parham](#) on Sat, 27 May 2006 14:28:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

For use in a corner, I'd go the other way. Instead of using an alignment with a steep cutoff, go for a slightly overdamped curve. That will work better as a conjugate for the bass boost provided by corner loading.

---