Subject: Corner loading
Posted by Wayne Parham on Sat, 27 May 2006 14:28:53 GMT
View Forum Message <> Reply to Message

For use in a corner, I'd go the other way. Instead of using an alignment with a steep cutoff, go for a slightly overdamped curve. That will work better as a conjugate for the bass boost provided by corner loading.