Posted by Wayne Parham on Tue, 23 Sep 2008 19:16:15 GMT
View Forum Message <> Reply to Message

That's a tough design choice, isn't it? Another thing to consider besides those you've mentioned is path length and how it affects summing. To get the sounds sources to sum properly, you'll need to delay everything else, otherwise phase will be way off.