

---

Subject: Re: Any ideas for a cabinet design?

Posted by [Wayne Parham](#) on Mon, 26 Jul 2004 02:56:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

To horn load the tweeter means you will mount it on a horn. If it isn't designed for that purpose, it probably won't be sensitive enough to match your midwoofer at 99dB/W/M.

---