
Subject: Re: Newest acquisition 2 - 8" full range from Roland

Posted by [roncla](#) on Tue, 14 Sep 2004 00:39:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

The pointy type pipes went out a long time ago. Its much better to make the throat (top section) at least equal to the S_d of the driver. The mouth (bottom section) should be around $4 \times S_d$. This will hold down ripple in given sections of the FR curve. Without T/S parameters its more or less of a crapshoot, unless you have methods to establish them. ron
