

---

Subject: Re: voight pipe plans for 206 Fostex  
Posted by [roncla](#) on Mon, 09 May 2005 21:54:45 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Well there is a major difference in Qts. Some added series resistance will help (4-6 ohms). Be sure to use at least 10 watt non inductive resistors. I had my original 206es in a break in, folded TQWT and it took the added series resistance to get an acceptable bass response.ron

---