

---

Subject: Re: requesting opinions on fullrange array  
Posted by [Wayne Parham](#) on Fri, 03 Jun 2005 20:11:12 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

You could install a potentiometer after the preamp output, in the line to the sub amp.

---