Subject: Re: requesting opinions on fullrange array
Posted by Wayne Parham on Fri, 03 Jun 2005 20:11:12 GMT
View Forum Message <> Reply to Message

You could install a potentiometer after the preamp output, in the line to the sub amp.