

---

Subject: Re: A couple of things

Posted by [Retsel](#) on Mon, 28 Aug 2006 21:43:03 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Dick Olsher relies on a 12 db/octave crossover for high passing the Lowther drivers. You may want to try a 18 db/octave crossover adjusting the bass driver to a 18 db/octave crossover as well. The second option is to crossover the Lowther at 200 hz instead of 150 hz. Retsel

---