

---

Subject: Re: Floor bounce

Posted by [akhilesh](#) on Wed, 16 May 2007 18:06:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

HI, You could put the BR port or TL port close to floor level, and the driver high up (listening height). This is the design most folks use. -akhilesh

---