

---

Subject: Re: smoothing Zobel? tick but not if result is less than 91db/w!

Posted by [Wayne Parham](#) on Sat, 15 Mar 2008 20:14:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

If you put any series capacitance in the circuit, i.e. high-pass, then you might want a Zobel. If you use inductance and capacitance, you'll almost definitely want a Zobel. But if you run the driver wide open with no crossover or just a bit of series inductance, you probably won't need a Zobel.

---