Subject: Power tapering Idea - Mass loading? Posted by flacoman on Wed, 12 Jan 2005 11:54:05 GMT

View Forum Message <> Reply to Message

Having read the white paper on line sources, I pondered the idea of mass-loading the outer drivers, rather than lowering the drive signal. By mass loading you lower the sensitivity and Fs, thus sneaking a little more extension out of the smallish drivers used. Bill: any thoughts?TIAJorge