
Subject: Re: Power tapering Idea - Mass loading ?
Posted by [Adrian Mack](#) on Fri, 14 Jan 2005 14:20:10 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hi Jorgel think you are referring to adding extra mass to the cone? You're 100% right - adding extra mass will lower F_s , lower sensitivity and will also raise Q_{ms} and hence Q_{ts} . It will reduce excursion-limited power handling though, if your intent is to use it at lower frequencies, which is what I think you want to do as you wouldn't add extra mass unless you wanted it to do deeper. Adrian
