

---

Subject: Re: please advice: 8 drivers, 95dB, 6ohm+  
Posted by [RKM](#) on Fri, 06 Jan 2006 01:47:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

1) Make 4 ohms work...get a new amplifier!2) Use an autoformer: it transforms from one impedance to another:<http://www.zeroimpedance.com/>or 'matchit' from parts express:<http://www.partsexpress.com/pe/showdetl.cfm?&DID=7&Partnumber=302-305>I have not personally used either of these, but I do use McIntosh amplifiers which incorporate autoformers to drive low impedance loads such as my DIY ribbon at 1 ohm.  
<http://www.zeroimpedance.com/>

---