

---

Subject: Re: internal pressure

Posted by [JP Hagggar](#) on Wed, 11 Oct 2006 14:32:06 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

ThanksOnce you get the cabinet dead sounding , there remains the standing waves ? I was thinking of using 2" standard 1lb ft3 and line the back and sides , then fill the rest with polyester fibers (the standard one used for upholstery ) like the picture of your array , leaving some breathing space for the air behind the drivers to the port .JP

---