
Subject: another ART array question....

Posted by [blake](#) on Sat, 17 Mar 2007 19:05:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

Trying to build the wiring harness. Anyone have any tips on soldering the quick disconnects to the end of the harness wire? I'm using 16 gauge solid for the harness. I can't seem to get the solder to run down the small gap between the wire and the disconnect. Did everyone else use something different for the harness wire? Thanks again Blake
