

---

Subject: Re: direct answer to Wayne

Posted by [Wayne Parham](#) on Wed, 21 Mar 2007 16:54:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I see, or at least I think I do. You're saying you want to double-check your wiring, right? If so, I'm not sure I can recommend a short-cut. You can measure total impedance for a "sanity check" - If it's way off then you'll know something is wrong. For example, one would expect a series/parallel

But there is no substitution for checking point-to-point connections. Even if you measure impedance and find it's right, you won't know that polarity is right for each driver without a response chart. Best to check your wiring, point-to-point.

---