

---

Subject: Re: passive crossover point

Posted by [zobsky](#) on Thu, 19 Jul 2007 04:03:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Forgot to mention, I'm thinking of 3rd order butterworth (tweeter line impedance is pretty much a flat 6 ohm, while the woofer line will need a zobel to hold it steady at 6 ohm)

---